



Product care

All of our products require very little care to keep them in tip top condition. If you follow these simple steps you'll be able to keep your product looking good and in great condition for many years to come.

Husky Retro

Before cleaning your Retro we recommend you unplug your appliance.

Cleaning the exterior

Your Retro has a beautifully painted exterior and we'd like to help you keep it that way. So, we recommend that you clean it using a microfibre cloth or something similar. That way you can ensure that there are no accidental scratches or marks and it keeps the Retro look just as stunning as the day you received it.

Cleaning the interior

To make life easier, we recommend that you remove all the items including the shelves first. We'd recommend cleaning the interior by simply wiping it with warm water and a neutral detergent.

Once you have cleaned the interior, dry all surfaces thoroughly.

If you need to clean the door seal then simply use mild soapy water. Dry the door seal after cleaning and that's it. Switch the unit back on and replace your contents.

Simple, easy and will leave your Retro looking as good as the day you received it.

Husky Wine Coolers

Before cleaning your wine cooler we recommend you unplug it first.

To make life easier, we recommend that you remove all the items including the shelves first.

Then using a damp cloth, soaked in a solution of two tablespoons of ordinary baking soda to a litre of water clean the interior of the wine cooler. Do not use abrasive cleaners as these will scratch the interior of your wine cooler.

Wash the shelves with a mild detergent solution and use this also for the outside of the wine cooler as well. Dry off the wine cooler and shelves and replace them back into the unit. Switch the unit back on and leave it to reach the desired temperature and then replace your contents.

Husky Drinks Coolers and Mini Fridges

Before cleaning either your drinks cooler or mini fridge we recommend that you unplug it first.

To make life easier, we recommend that you remove all the items including the shelves first.

Wash the interior with warm water and a neutral detergent, that way you'll ensure that there are no lingering odours of cleaning fluids within your unit.

Once you have cleaned the interior then dry all surfaces thoroughly .

And finally, if your door seal needs cleaning then use mild soapy water. Once clean dry off the seal switch the unit back on and replace your contents.